INSTALLATION MANUAL

Cut off power before installation













Replacing the lamp









Max. 10pcs interconnected



Attention:please check whether the lamp is fixed and wired properly
if the lamp doesn't work while switching on.
Please change fluorescent tube in time if the following situation occur:
1.Black spot/ring on two ends of fluorescent tube
2.Rolling lights in fluorescent tube
3.Unstable rays emitted by fluorescent tube

INSTRUCTIONS

Please operate strictly according to the Instruction
Don't modify the product randomly,only for indoor use

WARNING:

Apply to AC 220–240V 50Hz.

It is suitable for stable wall or wooden surface.

Do not use the lamp in a high temperature or humid area in order to avoid lamp damage.

The lamp is not designed for dimmer.

Ask a qualified electrician to inspect or install the lamp to avoid any danger.

Please ask a qualified electrician to maintain or replace the product when component is destroyed or the product work abnormally .

Please switch off the power supply before replacing bulb .